

Red
Medical Alarm

Push for
medical assistance

Blue
Phone

Push for voice
communication

Green
Mechanical Stop

Push to report a
mechanical stop



Transmit

LED turns green
during transmission

Voice

LED constant green
during telephone use

Lock GPS
Lock Iridium
Constant yellow LED

Power On

Constant red
LED

You are victim or witness of an accident

Press the red button if you need medical assistance, and then press the blue button to report the details to the Rally HQ

Call the HQ

Push the BLUE button AFTER pushing the RED or GREEN button for communication with the Rally HQ.
We will call you back

You have a mechanical problem

Press the green button, and then the blue button to report your situation.

In case of an accident: When you set off again, press the green button. For a stop more than 3 minutes, your stop time can be deducted.



Manual Alerts

To send an alert : push the red or green button. One button push is enough! Your exact position is sent to Rally HQ automatically

To speak with Rally HQ : push the blue button. One button push is enough! Wait for an Rally HQ voice contact to respond. Average response time is 3 minutes. Phones are dialing and connecting to you. Listen for the Iritrack box to talk to you. Stay focused!

Automatic Alert Function

Iritrack sent automatically an alert to the Rally HQ in the 2 cases below :

Violent impact (decelerometer) followed by a stop of 3 minutes

Abnormal inclination (inclinometer) followed by a stop of 3 minutes

Attention : if your motorcycle has suffered a severe fall, or you car / truck has rolled, the Iritrack may stop working, as the aerals may become disconnected or ripped out. If this happens, and only in this case, launch your distress beacon, if you are victim or witness to an accident.