



Scan to access the
Iritrack Tutorial video!



➕ Medical emergency

Press the **RED RESCUE**
button for three seconds

- Report a medical emergency for yourself or another competitor.
- The icon **RESCUE** appears on the screen.
- Race HQ confirms reception with an acknowledgment.
- **Stay close to the Iritrack** : race HQ will contact you through the Iritrack voice communication function.



Call race HQ

Press the **BLUE PHONE**
button for three seconds

- The icon  appears in the center of the screen.
- The device rings : an operator will answer through the Iritrack.



Temporary Stop

Press the **GREEN SEND**
button for three seconds

- Stops lasting several minutes in a safe location must be reported to help race control management.

Items to check on your Iritrack

Power supply

LED  : **steady or flashing**

Icons :  at the top of your screen, indicate that your device is properly powered.
 or   

Antennas

The status of the Iridium and GPS antennas is displayed on a white background by the icons  and .



Messaging

The LED  flashes when a message is received and the icon  appears.

Reply and send a message

Use the up and down arrows to access the "Reply" menu, then press "OK".

Then use the arrows to search for your pre-recorded reply, and press "OK" twice.